



ORDER BY PART NUMBER, NOT CODE NUMBER

CODE NO.	PART NO.	NO. REQ.	DESCRIPTION	CODE NO.	PART NO.	NO. REQ.	DESCRIPTION
1	4310	1	Stopper Assembly	23	8492AC	1	End Bell Assembly, Upper (Includes Codes 24 & 25)
2	5170AC	1	Flange, Strainer	24	4250	1	Seal, Water & Oil
3	1160	1	Gasket, Sink Flange	25	2292	1	Washer, Thrust
4	5150E	1	Flange, Backup	26	2592	1	Gasket, Tailpipe
5	5141	1	Flange, Mounting	27	8219	1	Tailpipe
6	5147	3	Screw, Backup	28	2593A	1	Flange, Tailpipe
7	5166	1	Ring, Retaining	29	1468	2	Screw, Tailpipe
8	70368	1	Gasket, Mounting	30	9341C	1	Stator Assembly
9	5298	1	Flange, Body	31	3253E	1	Rotor & Shaft Assembly (Includes Codes 32)
10	72248	1	Trim Shell	32	2642	1	Washer
11	2037	2	Clip, Trim Band	33	2467	1	Centrifugal Actuator, Switch
12	70984	1	Insulation	34	3706C	1	Switch Assembly, Start
13	72029A	4	Bolt, Thru	35	2267BY	1	Overload, Protector
14	9206M	1	Clamping Ring	36	4134	1	Shield, Wire
15	70985N	1	Body, Container (Includes Code 14)	37	71875	1	End Frame Assembly, Lower (Includes Code 40)
16	1473	1	O-Ring	38	71387	1	Cover, Terminal
17	70647	1	Sleeve & Seal Kit (Includes Codes 18 - 21)	39	70734	1	Screw, Terminal Cover
18	N/A	1	Nut, Flange	40	2466A	1	Screw, Ground
19	N/A	1	Slinger	41	72050	1	ICU Booklet
20	N/A	1	Seal		2638BE	1	Instruction Assy (Not Shown) (Includes Codes 26 - 29)
21	N/A	1	Sleeve				
22	3216B	1	Shredder Assembly, Rotating				