



ORDER BY PART NUMBER, NOT CODE NUMBER

CODE NO.	PART NO.	NO. REQ.	DESCRIPTION	CODE NO.	PART NO.	NO. REQ.	DESCRIPTION
1	4310	1	Stopper Assembly	18	N/A	1	Washer, Flanged
2	N/A	1	Flange, Strainer	19	N/A	1	Washer, Beveled
3	N/A	1	Seal, Sink Flange	20	N/A	1	Nut, 1 - 1/2" Slip
4	N/A	1	Flange, Backup	21	N/A	1	Tailpipe
5	N/A	1	Flange, Mounting	22	4577	1	Wrench, Emergency (Not Shown)
6	N/A	3	Screw, Backup	23	9341C	1	Stator Assembly
7	N/A	1	Ring, Retaining	24	3706C	1	Switch Assembly, Start
8	70368	1	Gasket, Mounting	25	2267CH	1	Overload, Protector
9	N/A	1	Flange, Body	26	71875	1	End Frame Assembly (Includes Code 27)
10	3173DA	1	Mounting Assy (Incl. Codes 2-7 & 9)	27	N/A	1	Screw, Ground
11	72487	1	Trim Shell (Incl. code 12)	28	4134	1	Shield, Wire
12	2037	2	Clip	29	72647A	1	Cover, Terminal Assy (Incl. Code 30)
13	70984	1	Insulation	30	N/A	1	Screw, Terminal Cover
14	72029A	4	Bolt, Thru	31	70661	1	Bushing (BV Plus-5A only)
15	N/A	1	Enclosure Assembly (Not Available - Replace Unit)	32	2272	1	Cord (BV Plus-5A only)
16	2467	1	Centrifugal Actuator Assy	33	72244	1	ICU Booklet (Not Shown)
17	72555	1	Kit, Installation (Includes codes 18 - 22)				