



**ORDER BY PART NUMBER, NOT CODE NUMBER**

CODE NO.	PART NO.	NO. REQ.	DESCRIPTION	CODE NO.	PART NO.	NO. REQ.	DESCRIPTION
1	5032A	1	Stopper Assembly	18	72678	1	Kit, Installation (Incl. codes 19-23)
2	N/A	1	Gasket, Stopper	19	N/A	1	Washer, Flanged
3	70966	1	Baffle	20	N/A	1	Washer, Beveled
4	N/A	1	Flange, Strainer	21	N/A	1	Nut, 1 - 1/2" Slip
5	N/A	1	Flange, Backup	22	N/A	1	Tailpipe
6	N/A	1	Flange, Mounting	23	4577	1	Wrench, Emergency (Not Shown)
7	N/A	3	Screw, Backup	24	8629A	1	Stator Assembly
8	N/A	1	Ring, Retaining	25	3706C	1	Switch Assembly, Start
9	70368	1	Gasket, Mounting	26	2267CH	1	Overload, Protector
10	N/A	1	Flange, Body	27	71875	1	End Frame Assembly (Includes Code 28)
11	3173EG	1	Mounting Assy (Incl. Codes 4-8 & 10)	28	N/A	1	Screw, Ground
12	71951A	1	Trim Shell Cap	29	4134	1	Shield, Wire
13	71975J	1	Trim Shell	30	72647A	1	Cover, Terminal Assy (Incl. Code 31)
14	71963	1	Insulation	31	N/A	1	Screw, Terminal Cover
15	72029A	4	Bolt, Thru	32	70666	1	Bushing (PRO 333-9A only)
16	N/A	1	Enclosure Assembly (Not Available - Replace Unit)	33	2272	1	Cord (PRO 333-9A only)
17	2467	1	Centrifugal Actuator Assy	34	72367	1	ICU Booklet (Not