



ORDER BY PART NUMBER, NOT CODE NUMBER

CODE NO.	PART NO.	NO. REQ	DESCRIPTION	CODE NO.	PART NO.	NO. REQ	DESCRIPTION
1	5032A	1	Stopper Assembly (Includes Code 2)	23	N/A	1	Seal
2	5029	1	Gasket, Stopper	24	N/A	1	Sleeve
3	70966	1	Baffle	25	71022	1	Shredder Assembly, Rotating
4	10025J	1	Flange, Strainer	26	9209C	1	End Bell Assembly, Upper
5	1160	1	Seal, Sink Flange	27	1470	1	Gasket, Tailpipe
6	5150E	1	Flange, Backup	28	8219	1	Tailpipe
7	5141	1	Flange, Mounting	29	5490	1	Flange, Tailpipe
8	5147	3	Screw, Backup	30	1491	1	Screw, Tailpipe
9	5166	1	Ring, Retaining	31	8628T	1	Stator Assembly
10	1010A	1	Gasket, Mounting	32	2467	1	Centrifugal Actuator Assembly
11	5298	1	Flange, Body	33	70422	1	Rotor & Shaft Assembly (Includes Codes 34)
12	71952	1	Trim Shell Cap	34	2642	1	Washer
13	71788	3	Screw, Tapping	35	70360	1	Switch Assembly, Start
14	9873	1	Body Container Assembly (Includes Code 15)	36	2267CH	1	Overload, Protector
15	2539	1	O-Ring	37	4134	1	Shield, Wire
16	71965	1	Insulation, Top	38	70424	1	End Frame Assembly, Lower (Includes Code 41)
17	72104A	1	Trim Shell, Assembly	39	71387	1	Cover, Terminal
18	71953A	1	Wrench Holder	40	70734	1	Screw, Terminal Cover
19	70647	1	Sleeve & Seal Kit (Includes Codes 20 - 24)	41	2466A	1	Screw, Ground
20	2854	1	Plug	42	2486A	2	Bolt, Thru
21	N/A	1	Bolt, Hexhead	43	72051	1	Use & Care Booklet
22	N/A	1	Slinger		2610ST	1	Instruction Assy (Not Shown) (Includes Codes 3, 27-30 & 43)